ShoreTel IP Phone 480/480g Quick Reference

PHONE OPERATION

Place Calls

Use the speakerphone or a headset



Use the Directory

Make a conference call

Make a call from History

Use the Intercom (through Directory)




Confer

Consult

Answer Calls

Answer a call



Send a call to voicemail



Divert an incoming call

+ Ext. + Transfer

Adjust volume of handset, headset, or speakerphone when off hook; adjust ringer volume when on hook

(- +) to select

Answer call waiting (incoming call)

Press green blinking call appearance button or **Answer**

Pick up a call for another extension

Pickup + Ext.

Interact with Calls

Mute a call



Place a call on hold

or press call appearance button

Take a call off hold

or press orange blinking call appearance button

Transfer a call

Merge calls into a conference call

Merge

Park a call on another extension

Park + Ext.

Unpark a call

Unpark + Ext.

VOICEMAIL

Check visual voicemail

Log in to voicemail main menu

Call VM + Password + # Voicemail

Log in from another extension

+ # + Ext.+ Password + # Voicemail

EXTENSION ASSIGNMENT

Using Phone Interface

Assign ext. to Available or Anonymous phone


Unassign extension



Assign your ext. to an assigned phone

Using Voicemail System

Change ext. assignment



Unassign extension

CUSTOMIZE YOUR PHONE

Select a ringtone



Change availability



Change avail. state and call forwarding






Change automatic off-hook setting





Change time zone

Log in or out of workgroup





Unassian

OK

OK

TROUBLESHOOTING

View phone information


+ 4 6 8 6 6 MNO # (INFO#)

Reboot your phone

Note: For details about using the phone, see the ShoreTel IP Phone 480/480g User Guide.



ShoreTel IP Phone 480/480g Quick Reference



GUIDE TO LEDS

Your ShoreTel 480/480g IP phone provides color cues to help you determine call appearance status:

- Steady Green: Phone is in use (dialing or off hook)
- Blinking Green: Incoming call
- ightharpoonup Blinking Orange: On hold or call parked
- Osteady Orange: Extension's availability state set to Do Not Disturb
- Steady Red: Monitored extension is in use by other party (applies to BCA and Extension Monitor)

In Directory and History (details view), the following icons indicate a person's current phone status:



Available



Custom availability state



On hold or has a call parked



Do not disturb



On a Call

GUIDE TO STATUS ICONS

Main Display



Unheard Voice Messages



Missed Calls



Logged in to Workgroup



Logged in to Workgroup, in Wrap-Up



Logged out of Workgroup



Available



In a Meeting or Do not Disturb



Out of Office



Vacation



Custom

Call Appearance



Idle, On Hook



Off Hook, Dialing



Inactive / Do Not Disturb



Incoming Call



Connected Call



Connected Conference Call



On Hold Locally



On Hold Remotely



Speed Dial Extension



Speed Dial Extension with DND



Call is being recorded



Whisper mute is active

Monitored Extension

Monitored extension



Monitored extension, DND



Unheard Messages





Connected call and incoming call





On a Conference Call



Monitored extension in a connected call and call answered locally



Monitored extension on hold and call answered locally



Monitored extension in a connected call with a call on hold

Visual Voicemail

Urgent





Message with return receipt



Q☐ Private message



Broadcast message



Broadcast message with return receipt requested



Private broadcast message



Private broadcast message with return receipt requested



Private message with return receipt requested